

CBRNE (DETECTOR/DECON KITS)

M256, M256A1, M291, M291A2, M258, M258A1, M72A2, M58A1, M295

POSSIBLE AREAS OF CONCERN

Contaminants of concern in the kits represent possible flammable and toxic hazards. Refer to SDS for specific use and handling procedures.

CHARACTERIZATION

The refill kit, when disposed of, is a **hazardous waste** for ignitability and toxicity.

HANDLING PROCEDURES

Note 1

M256/M256A1 and M258/M258A1 kits are tuned in to PPOC.

Note 2

M291/M291A2 and M295 kits are turned in through the JEAP (DoD Joint Equipment Assessment Program)

CBRNE Detector/ Decon Kits
M8; M9, M291; M295, M100,

Check the JEAP website for chemical items that may be able to be returned for training purposes:



NOTE: JEFS/DARD disposition request form instruction are located in Appendix E

This equipment will be disposed of through the Defense, Reutilization, Accountability and Disposal (DARD) program. The DARD office will require a Disposition Request Form to be completed to receive a TAC for the shipment. Please contact DARD to receive this form at the following:

- SMBLOGCOMJEAP@USMC.MIL

GENERAL INFORMATION

RSDL-Reactive Skin Decontamination Lotion-dispose of used/expired kits in refuse. CBRNE kits not covered by this protocol, contact **Environmental Division Hazardous Waste.**

CBRNE (PROTECTIVE MASK FILTERS)

M17/M17A1/M40/M40A1/M42

POSSIBLE AREAS OF CONCERN

The protective mask filters that contain ASC Whetlerite charcoal contain heavy metal chemical compounds (Chromium 6) and triethylenediamine.

CHARACTERIZATION

If these masks are equipped with the C2 (black body) ASC Whetlerized charcoal-filled canister NSN 4240-01-119-2315 or NSN 4240-21-871-7842, remove the C2 canister and manage as a **hazardous waste - chromium**. For those M40/M42 series masks containing the C2A1 (green body) ASZM TEDA charcoal-filled canister, NSN 4240-01-361-1319, remove the canister and collect separately from the black filters.

Note: CBRNF12B filters have a black body, but are not hazardous waste, and should be placed with the green filters.

CONTAINER MARKING AND HANDLING PROCEDURES

Note 1

C2 (black body) ASC Whetlerized charcoal-filled canister NSN 4240-01-119-2315 or NSN 4240-21-871-7842, are tuned in to PPOC.

Note 2

For those M40/M42 series masks containing the C2A1 (green body) ASZM TEDA charcoal-filled canister, NSN 4240-01-361-1319, remove the canister and collect separately from the black filters.

Note: CBRNF12B filters have a black body, but are not hazardous waste, and should be placed with the green filters. These filters are turned into your local SSA.

4240-01-529-2289



Protective Mask filters

GENERAL INFORMATION

These procedures do not cover any item that has been contaminated with agents. For information contact **Environmental Division Hazardous Waste**. Refer to protocol sheet A-21 for chemical/CBRNE related kits.